
### GROUNDWATER

The Flow of Water Through the Subsurface






Groundwater - 2nd largest source of fresh water on this planet.


### Where's the Water?

Parts of the Hydrosphere	Volume of Freshwater (km <sup>5</sup> )	Share of Total Volume of Freshwater (percent)
Ice sheets and glaciers	24,000,000	84.945
Groundwater	4,000,000	14.158
Lakes and reservoirs	155,000	0.549
Soll moisture	83,000	0.294
Water vapor in the atmosphere	14,000	0.049
River water	1,200	0.004
Total	28,253,200	100.000

### Where's the Rainfall?




# Water Consumption




# Rainfall vs. Consumption

- Consumption exceeds renewable water sources in the southwest.
- This is also true in Southern California since about 1900
- Also some places locally in the Midwest
- Necessitates the use of groundwater to meet human needs.


## Its All About Porosity...




# Intragranular Porosity




# Sediment Sorting and Porosity




## Intragranular Cement and Porosity




### Porosity in Shale



## Fracture Porosity



### Porosity and Burial



Loose, unconsolidated sediment

Consolidated sediment partly cemented

Well compacted and cemented sediments


# Porosity is important but...

...it isn't the whole story!

## Permeability

- Permeability = How well connected are the open spaces (porosity)
- Hydraulic Conductivity (k)
- Both porosity and permeability control the rate of groundwater flow along with...
- (Hint: What's the driving force?)
- GRAVITY!

### Darcy's Law



Q = Volume of water flowing


A = Crosssectional Area

K = hydraulic conductivity


h = height difference

1 = Distance traveled


#### The Water Table




- Downward infiltration from surface
- Percolation from influent streams
- Pore space completely filled = saturation
- Zone of saturation below water table.




### Water Table Characteristics






- •Aquafer has high porosity and permeability therefore allowing the transmission of water
- •Aquatard retards the flow of water through the sub surface
- •Aquaclude prohibits the flow of water through the subsurface


Springs often occur when groundwater is forced to the surface by an aquatard.



# Artesian Groundwater Systems



### Water Quality Issues - Source Area




Sandstone - Good pure water


Swampy source - Lots of organics


Limestone - High in calcium carbonate

# Cone of Depression




Overpumping can produce a large cone of depression causing shallow wells to go dry.






In the San Joaquin Valley of California, over-pumping has not only depleted aquafers but caused the ground to subside drastically.

### Salt Water Intrusion



Pumping causes a cone of depression and...

...draws the salt water upwards into the well.



### Groundwater - Some Main Points

- Part of the hydrologic system
- Subsurface flow of water
- Porosity and Permeability
- Fluid flow (Darcy's Law)
- Water table Zone of saturation
- Aquafers, Aquacludes, Aquatards
- Confined aquifers
- Effects of over pumping
- Effects on water quality.